



CONNECT 2-3 FOR 220vac
CONNECT 1-3 / 2-4 FOR 110vac

NOTE: See original schematic and circuit board layouts for values of other parts shown